

LOAD CHARTS NBT50

85% STABILITY ON OUTRIGGERS

SERIAL NUMBER

1

TABLE OF CONTENTS

GENERAL NOTES	4-5
WT. REDUCTIONS / LINE PULLS & REEVING INFO / HOIST PERFORMANCE	6
LIFTING AREA DIAGRAM / BASKET LMI OPERATING CODES	7
RANGE DIAGRAM w/ EXTENSION	8
ON OUTRIGGERS FULLY EXTENDED	
MAIN BOOM 360°	9
MAIN BOOM 360° with 26' FIXED or 26-45' TELE EXTENSION STOWED	. 10
MAIN BOOM 360° with 26' ERECTED or 26-45' TELE EXT ERECTED, RETRACTED	. 11
MAIN BOOM 360° with 26-45' TELE EXT ERECTED, EXTENDED	. 12
MAIN BOOM OVER REAR	. 13
MAIN BOOM OVER REAR with 26' FIXED or 26-45' TELE EXTENSION STOWED	. 14
EXTENSION 360°	. 15
EXTENSION OVER REAR	16
ON OUTRIGGERS 50% EXTENDED	
MAIN BOOM 360°	. 17
MAIN BOOM 360° with 26' FIXED or 26-45' TELE EXTENSION STOWED	. 18
MAIN BOOM 360° with 26' ERECTED or 26-45' TELE EXT ERECTED, RETRACTED	. 19
MAIN BOOM 360° with 26-45' TELE EXT ERECTED, EXTENDED	. 20
EXTENSION	21
ON OUTRIGGERS 0% EXTENDED	
MAIN BOOM 360°	22
MAIN BOOM 360° WITH 26' FIXED or 26-45' TELE EXTENSION STOWED	. 23

NOTES FOR LIFTING CAPACITIES

GENERAL:

- 1. Rated loads as shown on lift chart pertain to this machine as originally manufactured and equipped. Modifications to the machine or use of optional equipment other than that specified can result in a reduction of capacity.
- Construction equipment can be hazardous if improperly operated or maintained. Operation and maintenance of this
 machine shall be in compliance with the information in the Operator's and Safety Handbook, Service Manual and
 Parts Manual supplied with this machine. If these manuals are missing, order replacements from the manufacturer
 through the distributor.
- 3. The operator and other personnel associated with machine shall fully acquaint themselves with the latest American National Safety Standards (ASME/ANSI) for cranes.

SETUP

- The machine shall be level and on a firm supporting surface. Depending on the nature of the supporting surface, it may be necessary to have structural supports under the outrigger floats or tires to spread the load to a larger bearing surface.
- 2. For outrigger operation, all outriggers shall be properly extended with tires raised free of crane weight before operating the boom or lifting loads.
- 3. When machine is equipped with center front stabilizer, the front stabilizer shall be set in accordance with instructions in Operator's and Safety Handbook.
- 4. When equipped with removable and/or extendible counterweight, the proper counterweight shall be installed and fully extended before and during operation.
- 5. With certain boom and hoist tackle combinations, maximum capacities may not be obtainable with standard cable lengths.
- 6. Unless approved by the crane manufacturer, do not travel with boom extension or jib erected unless otherwise noted. Refer to Operator's and Safety Handbook for job-site travel information.
- 7. Inspect vehicle and crane including crane operation prior to use each day.
- 8. Always level the crane with the level indicator located at each outrigger control station.

OPERATION:

- 1. Rated loads at rated radius shall not be exceeded. Do not attempt to tip the machine to determine allowable loads. For clamshell, grapple, magnet or concrete bucket operation, weight of component and load must not exceed 80% of rated lifting capacities.
- 2. All rated loads have been tested to and meet the requirements of SAE J1063 Cantilevered Boom Crane Structures Method of Test, and do not exceed 85% of the tipping load on outriggers fully extended, and SAE J1289 Mobile Crane Stability Ratings [1.25P < (T-0.1A)] on outriggers 50% and 0% extended (fully retracted) as determined by SAE J765 Crane Stability Test Code.</p>
- 3. Rated loads include the weight of hookblock, slings and auxiliary lifting devices and their weights shall be subtracted from the listed rating to obtain the net load to be lifted. When more than the minimum required parts of line needed to pick the load are used, the additional rope weight as measured from the lower sheaves of the main boom nose shall be considered part of the load to be lifted. When both the hook block and headache ball are reeved, the lifting device that is NOT in use, including the line as measured from the lower sheave(s) of the nose supporting the unused device shall be considered part of the load.
- 4. Load ratings are based on freely suspended loads. No attempt shall be made to move a load horizontally on the ground in any direction.
- 5. The maximum in-service wind speed is 20 m.p.h. on the boom capacities and 15 m.p.h. on the extension capacities. It is recommended when wind velocity is above 20 m.p.h., rated loads and boom lengths shall be appropriately reduced. For machines not in-service, the main boom should be retracted and lowered with the swing brake set in wind velocities over 30 m.p.h.
- 6. Rated loads are for lift crane service only.
- 7. Do not operate at a radius or boom length where capacities are not listed. At these positions, the machine may overturn without any load on the hook.
- 8. The maximum load which can be telescoped is not definable because of variations in loadings and crane maintenance, but it is safe to attempt retraction and extension of the boom within the limits of the capacity chart.
- 9. When the boom length or lift radius or both are between values listed, the smallest load shown at either the next larger or shorter radius or next longer or shorter boom length shall be used.
- 10. For safe operation, the user shall make due allowances for his particular job conditions, such as: soft or uneven ground, out of level conditions, high winds, side loads, pendulum action, jerking or sudden stopping of loads, experience of personnel, two machine (tandem) lifts, traveling with loads, electric wires, obstacles, hazardous conditions, etc. Side pull on boom or extension is extremely dangerous.

NOTES FOR LIFTING CAPACITIES (cont'd.)

OPERATION (cont'd.):

- 11. When handling personnel, the requirements of the applicable national, state, and local regulations and safety codes must be met.
- 12. The boom angle before loading should be greater than the loaded boom angle to account for deflection.
- 13. Capacities appearing above the bold line are based on structural strength and tipping should not be relied upon as a capacity limitation.
- 14. When operating the machine in the "On Outriggers 50% Extended " mode, the outrigger beam pins must be engaged. When operating in the "On Outriggers 0% Extended " mode, the outrigger beams must be fully retracted. Failure to follow these precautions could result in structural damage or loss of stability of the machine.
- 15. Do not lift loads when boom is fully lowered. The Load Moment Indicator (LMI) senses pressure and will not provide warnings or lockout. The crane can become overloaded if lift cylinder(s) is fully retracted.
- 16. Use LMI/angle indicator as reference only.
- 17. Do not exceed extension capacities at any reduced boom length.
- 18. Capacities for the 31.7 ft. boom length shall be lifted with boom fully retracted. If boom is not fully retracted, capacities shall not exceed those shown for the 43 ft. boom length.
- 19. Always pay out load line before extending boom to avoid damaging loadline or crane structure or tripping anti-two-block system.
- 20. The maximum outrigger pad load is 76,000 lb (for a GVW of 19,760 lb minimum chassis requirement).
- 21. Loads lifted must be within safe winch capacity. Multiple part rope reeving must be used on loads exceeding winch single part rated pull. Auxiliary boom head rated for single part use except multi-reeve group used for nominal rated load. Extensions are rated for single part use only.
- 22. Do not operate the boom over personnel or allow them to walk or stand beneath the boom or load.
- 23. Do not allow personnel on carrier deck or crane frame area when rotating crane.
- 24. Do not allow personnel to ride on hook, hook block, load or any device attached to the loadline. Handling of personnel is only permitted with full extension of all outrigger beams. Use only National Crane approved baskets.
- 25. If using offset extension, do not use personnel basket with extension deployed at 30 degree offset.
- 26. Operate controls slowly and smoothly to avoid damage to crane or personnel.
- 27. Boom must be in carrying rack and outriggers fully retracted for travel.
- 28. Maintain a clearance of at least 10 feet between any part of the crane, loadline, or load, and any electrical line carrying up to 50,000 volts. One foot of clearance is required for every additional 30,000 volts or less.

DEFINITIONS:

- 1. <u>Operating Radius</u>: Horizontal distance from a projection of the axis of rotation to the supporting surface before loading to the center of the vertical hoist line or tackle with load applied.
- 2. <u>Loaded Boom Angle</u> (Shown in Parenthesis on Main Boom Capacity Chart): is the angle between the boom base section and the horizontal, after lifting the rated load at the rated radius with the rated boom length.
- 3. Working Area: Areas measured in a circular arc about the center line of rotation as shown on the working area diagram.
- 4. Freely Suspended Load: Load hanging free with no direct external force applied except by the lift cable.
- 5. Side Load: Horizontal force applied to the lifted load either on the ground or in the air.
- 6. No load stability limit: The stability limit radius is the radius beyond which it is not permitted to position the boom plus block configuration because machine can overturn without any load on the hook.
- 7. <u>Structural length limit</u>: An area where the boom, or the boom with jib deployed, cannot be extended because of structural limitations.

WEIGHT REDUCTIONS FOR LOAD HANDLING DEVICES

AUXILIARY BOOM NOSE	71 lb
HOOKBLOCKS and HEADACHE BALI	_S:
55 ton, 5 sheave (14" sheave) (CE)	1098 lb+
40 ton, 3 sheave (12" sheave)	600 lb+
20 ton, 1 sheave	400 lb+
7 ton overhaul ball	171 lb+

⁺Refer to rating plate for actual weight.

When lifting over boom extension, deduct total weight of all load handling devices reeved over main boom nose directly from boom extension capacity.

NOTE: All load handling devices and boom attachments are considered part of the load and suitable allowances MUST BE MADE for their combined weights. Weights are for Manitowoc furnished equipment.

LINE PULLS AND REEVING INFORMATION

HOISTS	CABLE SPECS.	PERMISSIBLE LINE PULLS	NOMINAL CABLE LENGTH
Main Standard	5/8" (16 mm) Dyform 34 LR Rotation Resistant (Non-rotating) Min. Breaking Strength 56,420 lb	11,280 lb	450 ft.
Main & Aux Optional	5/8" (16 mm) 6x19 Class EEIPS, IWRC Min. Breaking Strength 45,400 lb	11,280 lb	450 ft.


The approximate weight of 5/8" wire rope is 1.0 lb/ft.

Parts of line	1	2	3	4	5	6	7	8	9
Max. boom length (ft.) at max. elevation with stated rigging and load block at ground level	173 (includes 45' ext.)	128	102	81	66	55	47	40	35
Low speed lift (lb)	11280	22500	33750	45000	56250	67500	78750	90000	100000
High speed lift (lb)	5000	10000	15000	20000	25000	30000	35000	40000	45000

HOIST PERFORMANCE

\A/'	Hoist Li	ne Pulls	Drum	Dono
Wire	Two Spe	ed Hoist		Rope ity (ft.)
Rope Layer	Low	High	Сарас	ity (it.)
Layer	Available lb*	Available lb*	Layer	Total
1	15,000	7,516	82	82
2	13,529	6,765	92	174
3	12,299	6,150	101	275
4	11,275	5,637	110	385
5	10,407	5,204	119	504

^{*}Max. lifting capacity: Dyform 34 LR and 6x19 class = 11,280 lb



BOLD LINES DETERMINE THE LIMITING POSITION OF ANY LOAD FOR OPERATION WITHIN WORKING AREAS INDICATED WORKING AREA DIAGRAM


Basket LMI Operating Codes

0013 Basket

0014 Basket with 26 ft. fixed or 26-45 ft. tele extension stowed

0015 Basket with 26' fixed or 26' tele extension at 0° offset

0016 Basket with 26-45 ft. tele extension extended at 0° offset



^{*}THIS DRAWING SHOWS THE PHYSICAL REACH OF THE MACHINE. ALWAYS REFER TO LOAD CHART TO SEE WHICH PORTIONS OF THIS DIAGRAM ARE VALID FOR THE SPECIFIC MACHINE CONFIGURATION AND WHERE THE LOADS ARE STRUCTURALLY OR STABILITY LIMITED.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM

ON OUTRIGGERS FULLY EXTENDED - 360°

Radius			-	OLINO	#0001	LXIL		300		
in				M		ength in Fe	eet			
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128
8	100,000 (68.1)									
10	92,250 (64.0)	40,050 (71.3)								
12	80,100 (59.8)	40,050 (68.5)	40,350 (73.3)							
15	63,450 (53.1)	40,050 (64.0)	40,350 (69.9)	40,300 (73.5)						
20	46,300 (40.2)	40,050 (56.2)	40,350 (64.2)	40,300 (68.8)	34,100 (72.5)					
25	31,650 (21.8)	36,500 (47.5)	36,950 (57.9)	37,150 (63.9)	30,100 (68.4)	22,650 (71.5)				
30		28,950 (37.3)	29,400 (51.2)	29,700 (58.6)	27,100 (64.2)	20,400 (68.0)	17,800 (71.2)			
35		22,300 (23.6)	23,900 (43.8)	24,300 (53.0)	24,550 (59.8)	18,500 (64.3)	16,300 (68.0)	14,700 (70.8)	12,900 (73.2)	
40			18,600 (35.2)	18,950 (47.0)	19,250 (55.0)	17,050 (60.5)	15,100 (64.8)	13,650 (68.0)	12,050 (70.8)	10,850 (73.0)
45			14,800 (24.0)	15,150 (40.2)	15,450 (50.0)	15,650 (56.5)	14,000 (61.5)	12,550 (65.0)	11,300 (68.2)	10,250 (70.8)
50				12,350 (32.4)	12,600 (44.5)	12,800 (52.2)	12,850 (58.0)	11,750 (62.0)	10,650 (65.8)	9,650 (68.4)
55				10,300 (23.3)	10,600 (39.2)	10,800 (48.1)	11,000 (54.6)	10,950 (59.2)	10,000 (63.2)	8,750 (65.9)
60					8,850 (32.3)	9,050 (43.2)	9,250 (50.6)	9,400 (55.8)	9,400 (60.4)	7,850 (63.3)
65					7,450 (23.8)	7,650 (37.8)	7,800 (46.4)	7,950 (52.2)	8,100 (57.3)	7,000 (60.6)
70					*4,650 (9.2)	6,500 (31.7)	6,650 (41.9)	6,800 (48.5)	6,900 (54.0)	6,300 (57.9)
75						5,500 (24.2)	5,650 (37.0)	5,800 (44.5)	5,900 (50.7)	5,700 (55.0)
80						*4,400 (12.8)	4,800 (31.4)	4,950 (40.2)	5,050 (47.2)	5,150 (52.1)
85							4,100 (24.7)	4,200 (35.6)	4,300 (43.5)	4,400 (48.9)
90							3,450 (15.2)	3,550 (30.2)	3,650 (39.5)	3,750 (45.5)
95								3,000 (23.8)	3,100 (35.2)	3,200 (42.0)
100								2,500 (14.8)	2,600 (30.2)	2,700 (38.1)
105									2,150 (24.4)	2,250 (33.9)
110									1,750 (16.6)	1,800 (29.2)
115										1,450 (23.5)
120										*1,100 (15.8)
		oom angle					0	5	8	10
	Maximum	boom lengt	h (ft.) at 0°	boom angl	e (no load)			9	7	

NOTE: () Boom angles are in degrees. *Loads are structurally limited.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle												
Boom				Ma	ain Boom L	ength in Fe	eet						
Angle	31.7	43-A	54-B	64-C	75-D	86-E							
0°	12,900 (27.5)	7,600 (38.8)	4,850 (19.8)	3,700 (59.8)	2,200 (70.8)	1,150 (81.8)							

NOTE: () Reference radii in feet.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM WITH 26' FIXED or 26-45' TELE EXTENSION STOWED

ON OUTRIGGERS FULLY EXTENDED - 360°

Radius					#0002					
in Feet			1		ain Boom L					1
reet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128
8	98,850 (68.1)									
10	91,100 (64.0)	39,250 (71.3)								
12	78,950 (59.8)	39,250 (68.5)	39,250 (73.3)							
15	62,300 (53.1)	39,250 (64.0)	39,250 (69.9)	39,250 (73.5)						
20	45,150 (40.2)	39,250 (56.2)	39,250 (64.2)	39,250 (68.8)	33,650 (72.5)					
25	30,500 (21.8)	35,700 (47.5)	36,350 (57.9)	36,650 (63.9)	29,650 (68.4)	22,250 (71.5)				
30		28,150 (37.3)	28,800 (51.2)	29,200 (58.6)	26,650 (64.2)	20,000 (68.0)	17,450 (71.2)			
35		21,500 (23.6)	23,300 (43.8)	23,800 (53.0)	24,100 (59.8)	18,100 (64.3)	15,950 (68.0)	14,400 (70.8)	12,600 (73.2)	
40			18,000 (35.2)	18,450 (47.0)	18,800 (55.0)	16,650 (60.5)	14,750 (64.8)	13,350 (68.0)	11,750 (70.8)	10,600 (73.0)
45			14,200 (24.0)	14,650 (40.2)	15,000 (50.0)	15,250 (56.5)	13,650 (61.5)	12,250 (65.0)	11,000 (68.2)	10,000 (70.8)
50				11,850 (32.4)	12,150 (44.5)	12,400 (52.2)	12,500 (58.0)	11,450 (62.0)	10,350 (65.8)	9,400 (68.4)
55				9,800 (23.3)	10,150 (39.2)	10,400 (48.1)	10,650 (54.6)	10,650 (59.2)	9,700 (63.2)	8,500 (65.9)
60					8,400 (32.3)	8,650 (43.2)	8,900 (50.6)	9,100 (55.8)	9,100 (60.4)	7,600 (63.3)
65					7,000 (23.8)	7,250 (37.8)	7,450 (46.4)	7,650 (52.2)	7,800 (57.3)	6,750 (60.6)
70					*4,200 (9.2)	6,100 (31.7)	6,300 (41.9)	6,500 (48.5)	6,600 (54.0)	6,050 (57.9)
75						5,100 (24.2)	5,300 (37.0)	5,500 (44.5)	5,600 (50.7)	5,450 (55.0)
80						*4,000 (12.8)	4,450 (31.4)	4,650 (40.2)	4,750 (47.2)	4,900 (52.1)
85							3,750 (24.7)	3,900 (35.6)	4,000 (43.5)	4,150 (48.9)
90							3,100 (15.2)	3,250 (30.2)	3,350 (39.5)	3,500 (45.5)
95								2,700 (23.8)	2,800 (35.2)	2,950 (42.0)
100								2,200 (14.8)	2,300 (30.2)	2,450 (38.1)
105								,	1,850 (24.4)	2,000 (33.9)
110									1,450 (16.6)	1,550 (29.2)
115										1,200 (23.5)
120										*850 (15.8)
	Minimum b	ooom angle	(°) for indi	cated lengt	th (no load)		0	5	8	10
	Maximum	boom lengt	th (ft.) at 0°	boom angl	e (no load)			9	7	

NOTE: () Boom angles are in degrees. *Loads are structurally limited.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle											
Boom	oom Main Boom Length in Feet											
Angle	31.7	43-A	54-B	64-C	75-D	86-E						
0°	11,750 (27.5)	6,800 (38.8)	4,250 (19.8)	3,200 (59.8)	1,750 (70.8)	750 (81.8)						

NOTE: () Reference radii in feet.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM WITH 26' FIXED ERECTED or 26-45' EXT ERECTED, RETRACTED

ON OUTRIGGERS FULLY EXTENDED - 360°

De d'inte		#0017										
Radius in	Main Boom Length in Feet											
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128		
8	97,450 (68.1)		-				-		-			
10	89,700 (64.0)	37,700 (71.3)										
12	77,550 (59.8)	37,700 (68.5)	37,700 (73.3)									
15	60,900 (53.1)	37,700 (64.0)	37,700 (69.9)	37,700 (73.5)								
20	43,750 (40.2)	37,700 (56.2)	37,700 (64.2)	37,700 (68.8)	32,000 (72.5)							
25	29,100 (21.8)	34,150 (47.5)	34,700 (57.9)	35,000 (63.9)	28,000 (68.4)	20,550 (71.5)						
30		26,600 (37.3)	27,150 (51.2)	27,550 (58.6)	25,000 (64.2)	18,300 (68.0)	15,750 (71.2)					
35		19,950 (23.6)	21,650 (43.8)	22,150 (53.0)	22,450 (59.8)	16,400 (64.3)	14,250 (68.0)	12,650 (70.8)	10,900 (73.2)			
40			16,350 (35.2)	16,800 (47.0)	17,150 (55.0)	14,950 (60.5)	13,050 (64.8)	11,600 (68.0)	10,050 (70.8)	8,850 (73.0)		
45			12,550 (24.0)	13,000 (40.2)	13,350 (50.0)	13,550 (56.5)	11,950 (61.5)	10,500 (65.0)	9,300 (68.2)	8,250 (70.8)		
50				10,200 (32.4)	10,500 (44.5)	10,700 (52.2)	10,800 (58.0)	9,700 (62.0)	8,650 (65.8)	7,650 (68.4)		
55				8,150 (23.3)	8,500 (39.2)	8,700 (48.1)	8,950 (54.6)	8,900 (59.2)	8,000 (63.2)	6,750 (65.9)		
60					6,750 (32.3)	6,950 (43.2)	7,200 (50.6)	7,350 (55.8)	7,400 (60.4)	5,850 (63.3)		
65					5,350 (23.8)	5,550 (37.8)	5,750 (46.4)	5,900 (52.2)	6,100 (57.3)	5,000 (60.6)		
70					*2,550 (9.2)	4,400 (31.7)	4,600 (41.9)	4,750 (48.5)	4,900 (54.0)	4,300 (57.9)		
75						3,400 (24.2)	3,600 (37.0)	3,750 (44.5)	3,900 (50.7)	3,700 (55.0)		
80						*2,300 (12.8)	2,750 (31.4)	2,900 (40.2)	3,050 (47.2)	3,150 (52.1)		
85							2,050 (24.7)	2,150 (35.6)	2,300 (43.5)	2,400 (48.9)		
90							1,400 (15.2)	1,500 (30.2)	1,650 (39.5)	1,750 (45.5)		
95								950 (23.8)	1,100 (35.2)	1,200 (42.0)		
100								450 (14.8)	600 (30.2)	700 (38.1)		
	length (gle (°) for ir no load)		0	2	5	7	14	29	34		
Maximu		ngth (ft.) at one load)	0° boom				64					

NOTE: () Boom angles are in degrees.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle											
Boom												
Angle	31.7	43-A	54-B	64-C								
0°	10,350 (27.5)	5,250 (38.8)	2,600 (19.8)	1,550 (59.8)								

NOTE: () Reference radii in feet.

^{*}Loads are structurally limited.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM WITH 26-45' EXT ERECTED, EXTENDED

ON OUTRIGGERS FULLY EXTENDED - 360°

Radius					#0018					
in				Ma		ength in Fe	et			
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128
8	97,050 (68.1)									
10	89,300 (64.0)	37,400 (71.3)								
12	77,150 (59.8)	37,400 (68.5)	37,400 (73.3)							
15	60,500 (53.1)	37,400 (64.0)	37,400 (69.9)	37,400 (73.5)						
20	43,350 (40.2)	37,400 (56.2)	37,400 (64.2)	37,400 (68.8)	31,850 (72.5)					
25	28,700 (21.8)	33,850 (47.5)	34,500 (57.9)	34,800 (63.9)	27,850 (68.4)	20,450 (71.5)				
30		26,300 (37.3)	26,950 (51.2)	27,350 (58.6)	24,850 (64.2)	18,200 (68.0)	15,650 (71.2)			
35		19,650 (23.6)	21,450 (43.8)	21,950 (53.0)	22,300 (59.8)	16,300 (64.3)	14,150 (68.0)	12,550 (70.8)	10,800 (73.2)	
40			16,150 (35.2)	16,600 (47.0)	17,000 (55.0)	14,850 (60.5)	12,950 (64.8)	11,500 (68.0)	9,950 (70.8)	8,750 (73.0)
45			12,350 (24.0)	12,800 (40.2)	13,200 (50.0)	13,450 (56.5)	11,850 (61.5)	10,400 (65.0)	9,200 (68.2)	8,150 (70.8)
50				10,000 (32.4)	10,350 (44.5)	10,600 (52.2)	10,700 (58.0)	9,600 (62.0)	8,550 (65.8)	7,550 (68.4)
55				7,950 (23.3)	8,350 (39.2)	8,600 (48.1)	8,850 (54.6)	8,800 (59.2)	7,900 (63.2)	6,650 (65.9)
60					6,600 (32.3)	6,850 (43.2)	7,100 (50.6)	7,250 (55.8)	7,300 (60.4)	5,750 (63.3)
65					5,200 (23.8)	5,450 (37.8)	5,650 (46.4)	5,800 (52.2)	6,000 (57.3)	4,900 (60.6)
70					*2,400 (9.2)	4,300 (31.7)	4,500 (41.9)	4,650 (48.5)	4,800 (54.0)	4,200 (57.9)
75						3,300 (24.2)	3,500 (37.0)	3,650 (44.5)	3,800 (50.7)	3,600 (55.0)
80						*2,200 (12.8)	2,650 (31.4)	2,800 (40.2)	2,950 (47.2)	3,050 (52.1)
85							1,950 (24.7)	2,050 (35.6)	2,200 (43.5)	2,300 (48.9)
90							1,300 (15.2)	1,400 (30.2)	1,550 (39.5)	1,650 (45.5)
95								850 (23.8)	1,000 (35.2)	1,100 (42.0)
100									500 (30.2)	600 (38.1)
	n boom an length (i	no load)		0	3	6	10	18	29	36
Maximu	m boom ler angle (r	ngth (ft.) at (no load)	0° boom				64			

NOTE: () Boom angles are in degrees.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle											
Boom	Main Boom Length in Feet											
Angle	31.7	43-A	54-B	64-C								
0°	9,950 (27.5)	4,950 (38.8)	2,400 (19.8)	1,350 (59.8)								

NOTE: () Reference radii in feet.

^{*}Loads are structurally limited.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM

ON OUTRIGGERS FULLY EXTENDED - OVER REAR

Radius					#0003					
in				M	ain Boom L	ength in Fe	eet			
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128
8	100,000 (68.1)									
10	92,250 (64.0)	40,050 (71.3)								
12	80,100 (59.8)	40,050 (68.5)	40,350 (73.3)							
15	63,450 (53.1)	40,050 (64.0)	40,350 (69.9)	40,300 (73.5)						
20	46,300 (40.2)	40,050 (56.2)	40,350 (64.2)	40,300 (68.8)	34,100 (72.5)					
25	31,650 (21.8)	36,500 (47.5)	36,950 (57.9)	37,150 (63.9)	30,100 (68.4)	22,650 (71.5)				
30		28,950 (37.3)	29,400 (51.2)	29,700 (58.6)	27,100 (64.2)	20,400 (68.0)	17,800 (71.2)			
35		22,300 (23.6)	24,000 (43.8)	24,300 (53.0)	24,550 (59.8)	18,500 (64.3)	16,300 (68.0)	14,700 (70.8)	12,900 (73.2)	
40			20,000 (35.2)	20,300 (47.0)	20,550 (55.1)	17,050 (60.5)	15,100 (64.8)	13,650 (68.0)	12,050 (70.8)	10,850 (73.0)
45			16,400 (24.0)	16,800 (40.3)	17,050 (50.0)	15,800 (56.5)	14,000 (61.5)	12,550 (65.0)	11,300 (68.2)	10,250 (70.8)
50				13,900 (32.4)	14,150 (44.6)	14,350 (52.3)	12,850 (58.0)	11,750 (62.0)	10,650 (65.8)	9,650 (68.4)
55				11,650 (22.2)	11,900 (38.6)	12,100 (47.8)	12,000 (54.4)	10,950 (59.2)	10,000 (63.2)	8,750 (65.9)
60					10,200 (32.4)	10,400 (43.3)	10,550 (50.8)	10,300 (56.0)	9,400 (60.4)	7,850 (63.3)
65					8,700 (23.9)	8,900 (38.0)	9,050 (46.6)	9,200 (52.5)	8,850 (57.5)	7,000 (60.6)
70					*4,650 (9.2)	7,650 (31.8)	7,850 (42.1)	7,950 (48.7)	8,100 (54.4)	6,300 (57.9)
75						6,600 (24.3)	6,750 (37.2)	6,900 (44.8)	7,000 (51.0)	5,700 (55.0)
80						*4,400 (12.8)	5,850 (31.6)	6,000 (40.5)	6,100 (47.5)	5,150 (52.1)
85							5,100 (24.9)	5,200 (35.8)	5,300 (43.8)	4,650 (49.0)
90							*3,850 (15.3)	4,500 (30.5)	4,600 (39.8)	4,150 (45.7)
95							, ,	3,900 (24.1)	4,000 (35.5)	3,700 (42.2)
100								*2,800 (14.9)	3,450 (30.5)	3,300 (38.4)
105								-/	2,950 (24.7)	3,000 (34.3)
110									*2,400 (16.8)	2,600 (29.5)
115									(3.5)	*1,900 (23.7)
120										*1,100 (15.8)
		ooom angle	. ,		. ,		0	5	8	10
	Maximum	boom leng	th (ft.) at 0°	boom angl	e (no load)			9	7	

NOTE: () Boom angles are in degrees.

*Loads are structurally limited.
#LMI operating code. Refer to LMI manual for operating instructions

	Lifting Capacities at Zero Degree Boom Angle												
Boom		Main Boom Length in Feet											
Angle	31.7	43-A	54-B	64-C	75-D	86-E							
0°	12,900 (27.5)	7,600 (38.8)	4,850 (19.8)	3,700 (59.8)	2,200 (70.8)	1,150 (81.8)							

NOTE: () Reference radii in feet.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM WITH 26' FIXED or 26-45' TELE EXTENSION STOWED

ON OUTRIGGERS FULLY EXTENDED - OVER REAR

Radius					#0004						
in Feet						ength in Fe					
reet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128	
8	98,850 (68.1)										
10	91,100 (64.0)	39,250 (71.3)									
12	78,950 (59.8)	39,250 (68.5)	39,250 (73.3)								
15	62,300 (53.1)	39,250 (64.0)	39,250 (69.9)	39,250 (73.5)							
20	45,150 (40.2)	39,250 (56.2)	39,250 (64.2)	39,250 (68.8)	33,650 (72.5)						
25	30,500 (21.8)	35,700 (47.5)	36,350 (57.9)	36,650 (63.9)	29,650 (68.4)	22,250 (71.5)					
30		28,150 (37.3)	28,800 (51.2)	29,200 (58.6)	26,650 (64.2)	20,000 (68.0)	17,450 (71.2)				
35		21,500 (23.6)	23,400 (43.8)	23,800 (53.0)	24,100 (59.8)	18,100 (64.3)	15,950 (68.0)	14,400 (70.8)	12,600 (73.2)		
40			19,400 (35.2)	19,800 (47.0)	20,100 (55.1)	16,650 (60.5)	14,750 (64.8)	13,350 (68.0)	11,750 (70.8)	10,600 (73.0)	
45			15,800 (24.0)	16,300 (40.3)	16,600 (50.0)	15,400 (56.5)	13,650 (61.5)	12,250 (65.0)	11,000 (68.2)	10,000 (70.8)	
50			Ì	13,400 (32.4)	13,700 (44.6)	13,950 (52.3)	12,500 (58.0)	11,450 (62.0)	10,350 (65.8)	9,400 (68.4)	
55				11,150 (22.2)	11,450 (38.6)	11,700 (47.8)	11,650 (54.4)	10,650 (59.2)	9,700 (63.2)	8,500 (65.9)	
60					9,750 (32.4)	10,000 (43.3)	10,200 (50.8)	10,000 (56.0)	9,100 (60.4)	7,600 (63.3)	
65					8,250 (23.9)	8,500 (38.0)	8,700 (46.6)	8,900 (52.5)	8,550 (57.5)	6,750 (60.6)	
70					*4,200 (9.2)	7,250 (31.8)	7,500 (42.1)	7,650 (48.7)	7,800 (54.4)	6,050 (57.9)	
75					(-)	6,200 (24.3)	6,400 (37.2)	6,600 (44.8)	6,700 (51.0)	5,450 (55.0)	
80						*4,000 (12.8)	5,500 (31.6)	5,700 (40.5)	5,800 (47.5)	4,900 (52.1)	
85						(12.0)	4,750 (24.9)	4,900 (35.8)	5,000 (43.8)	4,400 (49.0)	
90							*3,500 (15.3)	4,200 (30.5)	4,300 (39.8)	3,900 (45.7)	
95							(10.0)	3,600 (24.1)	3,700 (35.5)	3,450 (42.2)	
100								*2,500 (14.9)	3,150 (30.5)	3,050 (38.4)	
105								(14.5)	2,650 (24.7)	2,750 (34.3)	
110									*2,100	2,350	
115									(16.8)	(29.5) *1,650	
120										(23.7) *850 (15.8)	
	Minimum b	oom angle	(°) for indi	cated lengt	h (no load)		0	5	8	(15.8) 10	
		boom lengt	()	U	, ,		97				

NOTE: () Boom angles are in degrees. *Loads are structurally limited.

#LMI operating code. Refer to LMI manual for operating instructions.

#LIVII OPEI	Lifting Capacities at Zero Degree Boom Angle											
Boom	Boom Main Boom Length in Feet											
Angle	31.7	43-A	54-B	64-C	75-D	86-E						
0°	11,750 (27.5)	6,800 (38.8)	4,250 (19.8)	3,200 (59.8)	1,750 (70.8)	750 (81.8)						

NOTE: () Reference radii in feet.

26 FT. FIXED AND 26 FT. - 45 FT. TELE OFFSETTABLE BOOM EXTENSION ON OUTRIGGERS FULLY EXTENDED - 360°

	**26 ft. L	ENGTH	45 ft. L	ENGTH	
Radius in	#0005	#0007	#0009	#0011	
Feet	0° OFFSET	30° OFFSET	0° OFFSET	30° OFFSET	
50	6,000 (72.6)				
55	5,800 (70.8)				
60	5,500 (69.0)				
65	5,200 (67.0)	4,900 (72.1)	4,050 (70.4)		
70	4,850 (65.0)	4,650 (69.9)	4,000 (68.8)		
75	4,500 (62.9)	4,400 (67.7)	3,950 (67.2)	2,800 (73.8)	
80	4,250 (60.8)	4,150 (65.4)	3,900 (65.6)	2,700 (71.9)	
85	3,950 (58.6)	4,000 (63.1)	3,800 (63.9)	2,650 (70.0)	
90	3,600 (56.2)	3,800 (60.7)	3,550 (62.0)	2,600 (68.0)	
95	3,000 (53.6)	3,550 (58.2)	3,250 (59.9)	2,550 (66.0)	
100	2,450 (50.9)	2,950 (55.3)	3,000 (57.8)	2,500 (63.9)	
105	2,000 (48.2)	1,450 (51.5)	2,700 (55.6)	2,450 (61.8)	
110	1,600 (45.3)	1,950 (49.1)	2,400 (53.3)	2,400 (59.5)	
115	1,200 (42.2)	1,500 (45.8)	2,000 (50.8)	2,350 (57.2)	
120	850 (39.0)	1,100 (42.4)	1,650 (48.3)	2,200 (54.6)	
125	550 (35.6)	750 (38.6)	1,300 (45.6)	1,800 (51.6)	
130	(66.6)	(00.0)	1,000 (42.8)	1,450 (48.5)	
135			700 (39.8)	1,050 (45.2)	
140			450 (36.7)	800 (41.7)	
145			(50.7)	500 (37.9)	
Min. boom angle for indicated length (no load)	34°	34°	36°	36°	
Max. boom length at 0° boom angle (no load)	6	4 ft.	64 ft.		

NOTE: () Boom angles are in degrees.

80034857A

#LMI operating code. Refer to LMI manual for instructions.
**26 ft. capacities are applicable to both 26' fixed and 26' tele
extension

BOOM EXTENSION CAPACITY NOTES:

- 1. All capacities above the bold line are based on structural strength limitations.
- 2. 26 ft. and 45 ft. extension lengths may be used for single line lifting service.
- 3. Radii listed are for a fully extended boom with the boom extension erected. For main boom lengths less than fully extended, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is configured. For boom angles not shown, use the rating of the next lower boom angle.

WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.

- Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- Capacities listed are with outriggers properly extended and vertical jacks set only.

26 FT. FIXED AND 26 FT. - 45 FT. TELE OFFSETTABLE BOOM EXTENSION ON OUTRIGGERS FULLY EXTENDED - OVER REAR

	**26 ft. L	ENGTH	45 ft. L	ENGTH		
Radius in	#0006	#0008	#0010	#0012		
Feet	0°	30°	0°	30°		
	OFFSET	OFFSET	OFFSET	OFFSET		
50	6,000 (72.6)					
55	5,800 (70.8)					
60	5,500 (69.0)					
65	5,200 (67.0)	4,900 (72.1)	4,050 (70.4)			
70	4,850 (65.0)	4,650 (69.9)	4,000 (68.8)			
75	4,500	4,400	3,950	2,800		
	(62.9)	(67.7)	(67.2)	(73.8)		
80	4,250	4,150	3,900	2,700		
	(60.8)	(65.4)	(65.6)	(71.9)		
85	3,950	4,000	3,800	2,650		
	(58.6)	(63.1)	(63.9)	(70.0)		
90	3,800	3,800	3,550	2,600		
	(56.4)	(60.7)	(62.0)	(68.0)		
95	3,650	3,650	3,250	2,550		
	(54.1)	(58.3)	(59.9)	(66.0)		
100	3,150	3,350	3,000	2,500		
	(51.5)	(55.6)	(57.8)	(63.9)		
105	2,600	2,900	2,700	2,450		
	(48.6)	(52.6)	(55.6)	(61.8)		
110	2,100	2,550	2,500	2,400		
	(45.7)	(49.6)	(53.5)	(59.5)		
115	1,700	2,150	2,300	2,350		
	(42.6)	(46.3)	(51.2)	(57.2)		
120	1,350	1,650	2,050	2,300		
	(39.4)	(42.8)	(48.7)	(54.7)		
125	950	1,200	1,750	2,250		
	(35.9)	(39.0)	(46.1)	(52.1)		
130	650	850	1,500	2,100		
	(32.1)	(34.8)	(43.4)	(49.2)		
135	, ,	450 (30.0)	1,200 (40.4)	1,700 (45.8)		
140		, ,	900 (37.3)	*1,350 (42.3)		
145			650 (33.9)	*900 (38.3)		
150			` /	*600 (33.9)		
Min. boom angle for indicated length (no load)	29°	30°	30°	31°		
Max. boom length at 0° boom angle (no load)	6	4 ft.	64 ft.			

NOTE: () Boom angles are in degrees.

BOOM EXTENSION CAPACITY NOTES:

- All capacities above the bold line are based on structural strength limitations
- 2. 26 ft. and 45 ft. extension lengths may be used for single line lifting service.
- 3. Radii listed are for a fully extended boom with the boom extension erected. For main boom lengths less than fully extended, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is configured. For boom angles not shown, use the rating of the next lower boom angle.

WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.

- Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- Capacities listed are with outriggers properly extended and vertical jacks set only.

[#]LMI operating code. Refer to LMI manual for instructions.

^{*}Capacities are structurally limited.

^{**26} ft. capacities are applicable to both 26' fixed and 26' tele extension.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM

ON OUTRIGGERS 50% EXTENDED - 360°

Radius					#0401					
in				Ma	ain Boom L	ength in Fe	et			
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128
8	100,000 (68.1)									
10	92,250 (64.0)	40,050 (71.3)								
12	80,100 (59.8)	40,050 (68.5)	40,350 (73.3)							
15	57,600 (53.1)	40,050 (64.0)	40,350 (69.9)	40,300 (73.5)						
20	30,800 (40.2)	31,950 (56.2)	32,600 (64.0)	33,050 (68.7)	33,500 (72.4)					
25	19,600 (21.8)	20,700 (47.4)	21,250 (57.8)	21,600 (63.6)	21,900 (68.1)	22,200 (71.5)				
30		14,500 (37.2)	15,050 (51.1)	15,350 (58.3)	15,650 (63.7)	15,850 (67.7)	16,150 (71.0)			
35		10,550 (25.2)	11,100 (44.4)	11,350 (52.7)	11,600 (59.2)	11,800 (63.9)	12,050 (67.6)	12,250 (70.5)	12,500 (73.2)	
40			8,350 (36.0)	8,650 (47.3)	8,850 (55.0)	9,050 (60.3)	9,250 (64.5)	9,400 (67.6)	9,600 (70.5)	9,750 (72.8)
45			6,450 (25.2)	6,750 (40.7)	7,000 (50.0)	7,150 (56.3)	7,300 (61.0)	7,450 (64.5)	7,650 (67.7)	7,800 (70.2)
50				5,200 (33.0)	5,450 (44.7)	5,600 (52.1)	5,750 (57.5)	5,900 (61.3)	6,000 (64.8)	6,150 (67.5)
55				4,000 (23.1)	4,200 (38.8)	4,350 (47.6)	4,500 (53.7)	4,650 (58.1)	4,750 (61.9)	4,850 (64.8)
60					3,200 (32.0)	3,400 (42.7)	3,500 (49.8)	3,600 (54.7)	3,750 (59.0)	3,800 (62.1)
65					2,400 (23.5)	2,550 (37.4)	2,700 (45.7)	2,800 (51.2)	2,900 (55.9)	2,950 (59.3)
70					1,700 (9.1)	1,850 (31.2)	2,000 (41.2)	2,100 (47.5)	2,200 (52.7)	2,250 (56.5)
75						1,300 (23.8)	1,400 (36.3)	1,500 (43.5)	1,600 (49.4)	1,650 (53.6)
80						750 (12.5)	900 (30.7)	1,000 (39.3)	1,050 (46.0)	1,150 (50.6)
85							450 (24.0)	550 (34.7)	600 (42.3)	700 (47.4)
Minir	num boom	angle (°) fo	r indicated	length (no	load)	0	23	33	40	45
Maxi	mum boom	length (ft.)	at 0° boom	angle (no	load)			86		

NOTE: () Boom angles are in degrees.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle											
Boom				Ma	ain Boom L	ength in Fe	eet					
Angle	31.7	43-A	54-B	64-C	75-D	86-E						
0°	12,900 (27.5)	7,600 (38.8)	4,850 (19.8)	3,000 (59.8)	1,550 (70.8)	600 (81.8)						

NOTE: () Reference radii in feet.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM WITH 26' FIXED or 26-45' TELE EXTENSION STOWED

ON OUTRIGGERS 50% EXTENDED - 360°

Radius					#0402	02					
in				Ma	ain Boom L	ength in Fe	et				
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128	
8	98,850 (68.1)										
10	91,100 (64.0)	39,250 (71.3)									
12	78,950 (59.8)	39,250 (68.5)	39,250 (73.3)								
15	56,450 (53.1)	39,250 (64.0)	39,250 (69.9)	39,250 (73.5)							
20	29,650 (40.2)	31,150 (56.2)	32,000 (64.0)	32,550 (68.7)	33,050 (72.4)						
25	18,450 (21.8)	19,900 (47.4)	20,650 (57.8)	21,100 (63.6)	21,450 (68.1)	21,800 (71.5)					
30		13,700 (37.2)	14,450 (51.1)	14,850 (58.3)	15,200 (63.7)	15,450 (67.7)	15,800 (71.0)				
35		9,750 (25.2)	10,500 (44.4)	10,850 (52.7)	11,150 (59.2)	11,400 (63.9)	11,700 (67.6)	11,950 (70.5)	12,200 (73.2)		
40			7,750 (36.0)	8,150 (47.3)	8,400 (55.0)	8,650 (60.3)	8,900 (64.5)	9,100 (67.6)	9,300 (70.5)	9,500 (72.8)	
45			5,850 (25.2)	6,250 (40.7)	6,550 (50.0)	6,750 (56.3)	6,950 (61.0)	7,150 (64.5)	7,350 (67.7)	7,550 (70.2)	
50				4,700 (33.0)	5,000 (44.7)	5,200 (52.1)	5,400 (57.5)	5,600 (61.3)	5,700 (64.8)	5,900 (67.5)	
55				3,500 (23.1)	3,750 (38.8)	3,950 (47.6)	4,150 (53.7)	4,350 (58.1)	4,450 (61.9)	4,600 (64.8)	
60					2,750 (32.0)	3,000 (42.7)	3,150 (49.8)	3,300 (54.7)	3,450 (59.0)	3,550 (62.1)	
65					1,950 (23.5)	2,150 (37.4)	2,350 (45.7)	2,500 (51.2)	2,600 (55.9)	2,700 (59.3)	
70					1,250 (9.1)	1,450 (31.2)	1,650 (41.2)	1,800 (47.5)	1,900 (52.7)	2,000 (56.5)	
75						900 (23.8)	1,050 (36.3)	1,200 (43.5)	1,300 (49.4)	1,400 (53.6)	
80							550 (30.7)	700 (39.3)	750 (46.0)	900 (50.6)	
85										450 (47.4)	
Minir	Minimum boom angle (°) for indicated length (no load)					0	23	33	40	45	
Maxi	Maximum boom length (ft.) at 0° boom angle (no load)							86			

NOTE: () Boom angles are in degrees.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle													
Boom		Main Boom Length in Feet												
Angle	31.7	43-A	54-B	64-C	75-D									
0°	11,750 (27.5)	6,800 (38.8)	4,250 (19.8)	2,500 (59.8)	1,100 (70.8)									

NOTE: () Reference radii in feet.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM WITH 26' FIXED ERECTED or 26-45' EXT ERECTED, RETRACTED ON OUTRIGGERS 50% EXTENDED - 360°

Radius					#0417					
in				Ma	ain Boom L	ength in Fe	eet			
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128
8	97,450 (68.1)									
10	89,700 (64.0)	37,700 (71.3)								
12	77,550 (59.8)	37,700 (68.5)	37,700 (73.3)							
15	55,050 (53.1)	37,700 (64.0)	37,700 (69.9)	37,700 (73.5)						
20	28,250 (40.2)	29,600 (56.2)	30,350 (64.0)	30,900 (68.7)	31,400 (72.4)					
25	17,050 (21.8)	18,350 (47.4)	19,000 (57.8)	19,450 (63.6)	19,800 (68.1)	20,100 (71.5)				
30		12,150 (37.2)	12,800 (51.1)	13,200 (58.3)	13,550 (63.7)	13,750 (67.7)	14,100 (71.0)			
35		8,200 (25.2)	8,850 (44.4)	9,200 (52.7)	9,500 (59.2)	9,700 (63.9)	10,000 (67.6)	10,200 (70.5)	10,500 (73.2)	
40			6,100 (36.0)	6,500 (47.3)	6,750 (55.0)	6,950 (60.3)	7,200 (64.5)	7,350 (67.6)	7,600 (70.5)	7,750 (72.8)
45			4,200 (25.2)	4,600 (40.7)	4,900 (50.0)	5,050 (56.3)	5,250 (61.0)	5,400 (64.5)	5,650 (67.7)	5,800 (70.2)
50				3,050 (33.0)	3,350 (44.7)	3,500 (52.1)	3,700 (57.5)	3,850 (61.3)	4,000 (64.8)	4,150 (67.5)
55				1,850 (23.1)	2,100 (38.8)	2,250 (47.6)	2,450 (53.7)	2,600 (58.1)	2,750 (61.9)	2,850 (64.8)
60					1,100 (32.0)	1,300 (42.7)	1,450 (49.8)	1,550 (54.7)	1,750 (59.0)	1,800 (62.1)
65						450 (37.4)	650 (45.7)	750 (51.2)	900 (55.9)	950 (59.3)
Minimur		gle (°) for ir no load)	ndicated	0	27	37	45	50	54	57
Maximum	ximum boom length (ft.) at 0° boom angle (no load)									

NOTE: () Boom angles are in degrees.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle											
Boom		Main Boom Length in Feet										
Angle	31.7	43-A	54-B	64-C								
0°	10,350 (27.5)	5,250 (38.8)	2,600 (19.8)	850 (59.8)								

NOTE: () Reference radii in feet.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM WITH 26-45' EXT ERECTED, EXTENDED

ON OUTRIGGERS 50% EXTENDED - 360°

Radius				#0418							
in				Ma	ain Boom L	ength in Fe	eet				
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128	
8	97,050 (68.1)										
10	89,300 (64.0)	37,400 (71.3)									
12	77,150 (59.8)	37,400 (68.5)	37,400 (73.3)								
15	54,650 (53.1)	37,400 (64.0)	37,400 (69.9)	37,400 (73.5)							
20	27,850 (40.2)	29,300 (56.2)	30,150 (64.0)	30,700 (68.7)	31,250 (72.4)						
25	16,650 (21.8)	18,050 (47.4)	18,800 (57.8)	19,250 (63.6)	19,650 (68.1)	20,000 (71.5)					
30		11,850 (37.2)	12,600 (51.1)	13,000 (58.3)	13,400 (63.7)	13,650 (67.7)	14,000 (71.0)				
35		7,900 (25.2)	8,650 (44.4)	9,000 (52.7)	9,350 (59.2)	9,600 (63.9)	9,900 (67.6)	10,100 (70.5)	10,400 (73.2)		
40			5,900 (36.0)	6,300 (47.3)	6,600 (55.0)	6,850 (60.3)	7,100 (64.5)	7,250 (67.6)	7,500 (70.5)	7,650 (72.8)	
45			4,000 (25.2)	4,400 (40.7)	4,750 (50.0)	4,950 (56.3)	5,150 (61.0)	5,300 (64.5)	5,550 (67.7)	5,700 (70.2)	
50				2,850 (33.0)	3,200 (44.7)	3,400 (52.1)	3,600 (57.5)	3,750 (61.3)	3,900 (64.8)	4,050 (67.5)	
55				1,650 (23.1)	1,950 (38.8)	2,150 (47.6)	2,350 (53.7)	2,500 (58.1)	2,650 (61.9)	2,750 (64.8)	
60					950 (32.0)	1,200 (42.7)	1,350 (49.8)	1,450 (54.7)	1,650 (59.0)	1,700 (62.1)	
65							550 (45.7)	650 (51.2)	800 (55.9)	850 (59.3)	
Minimur	Minimum boom angle (°) for indicated length (no load)			0	28	39	45	50	55	58	
Maximu	Maximum boom length (ft.) at 0° boom angle (no load)				64						

NOTE: () Boom angles are in degrees. #LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle											
Boom		Main Boom Length in Feet										
Angle	31.7	43-A	54-B	64-C								
0°	9,950 (27.5)	4,950 (38.8)	2,400 (19.8)	650 (59.8)								

NOTE: () Reference radii in feet.

26 FT. FIXED AND 26 FT. - 45 FT. TELE OFFSETTABLE BOOM EXTENSION

ON OUTRIGGERS 50% EXTENDED - 360°

	**26 ft. L	ENGTH	45 ft. L	ENGTH		
Radius in	#0405	#0407	#0409	#0411		
Feet	0° OFFSET	30° OFFSET	0° OFFSET	30° OFFSET		
50	6,000 (72.6)					
55	4,800 (70.4)					
60	3,700 (68.1)					
65	2,750 (65.7)	3,950 (71.5)	3,800 (70.2)			
70	2,000 (63.4)	3,050 (68.9)	3,000 (68.1)			
75	1,350 (61.0)	2,300 (66.2)	2,300 (65.9)	2,800 (73.8)		
80	800 (58.7)	1,600 (63.6)	1,700 (63.7)	2,700 (71.9)		
85		1,050 (61.0)	1,200 (61.5)	2,500 (69.8)		
90		550 (58.3)	750 (59.3)	1,900 (67.3)		
95				1,400 (64.8)		
100				950 (62.3)		
105				550 (59.7)		
Min. boom angle for indicated length (no load)	57°	58°	58°	59°		
Max. boom length at 0° boom angle (no load)	6	4 ft.	64 ft.			

NOTE: () Boom angles are in degrees.

80034859A

BOOM EXTENSION CAPACITY NOTES:

- All capacities above the bold line are based on structural strength limitations.
- 2. 26 ft. and 45 ft. extension lengths may be used for single line lifting service.
- 3. Radii listed are for a fully extended boom with the boom extension erected. For main boom lengths less than fully extended, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is configured. For boom angles not shown, use the rating of the next lower boom angle.

WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.

- Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- Capacities listed are with outriggers properly extended and vertical jacks set only

[#]LMI operating code. Refer to LMI manual for instructions.
**26 ft capacities are applicable to both 26' fixed and 26'

^{**26} ft. capacities are applicable to both 26' fixed and 26' tele extension.

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM

ON OUTRIGGERS 0% EXTENDED - 360°

Radius					#0801					
in				Ма	ain Boom L	ength in Fe	eet			
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128
8	60,700 (68.0)									
10	38,500 (64.0)	39,700 (71.3)								
12	27,200 (59.8)	28,250 (68.4)	28,900 (73.2)							
15	17,950 (53.1)	18,850 (63.9)	19,400 (69.7)	19,750 (73.2)						
20	10,100 (41.6)	11,000 (56.9)	11,450 (63.8)	11,750 (68.3)	12,000 (71.8)					
25	6,100 (24.2)	6,950 (48.3)	7,400 (58.2)	7,700 (63.8)	7,900 (68.1)	8,100 (71.2)				
30		4,350 (38.3)	4,800 (51.6)	5,050 (58.6)	5,250 (63.8)	5,400 (67.5)	5,550 (70.5)			
35		2,550 (25.2)	3,000 (44.3)	3,250 (53.1)	3,450 (59.3)	3,600 (63.8)	3,700 (67.2)	3,850 (69.7)	3,950 (72.0)	
40			1,700 (35.9)	1,950 (47.1)	2,150 (54.7)	2,250 (59.9)	2,400 (63.8)	2,500 (66.7)	2,600 (69.3)	2,650 (71.2)
45			700 (25.1)	950 (40.5)	1,150 (49.8)	1,300 (55.9)	1,400 (60.4)	1,450 (63.6)	1,550 (66.5)	1,650 (68.7)
50						500 (51.7)	600 (56.9)	700 (60.5)	750 (63.7)	800 (66.1)
Minimum boom angle (°) for indicated length (no load)		0	22	35	45	51	56	59	63	65
(ft.) at 0° b	ooom length ooom angle load)					43				

NOTE: () Boom angles are in degrees.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle												
Boom		Main Boom Length in Feet											
Angle	31.7	43-A											
0°	4,850 (27.5)	1,400 (38.8)											

NOTE: () Reference radii in feet.

80034855A

RATED LIFTING CAPACITIES IN POUNDS 31.7 FT. - 128 FT. BOOM WITH 26' FIXED or 26-45' TELE EXTENSION STOWED

ON OUTRIGGERS 0% EXTENDED - 360°

Radius					#0802					
in				Ma	ain Boom L	ength in Fe	eet			
Feet	31.7	43-A	54-B	64-C	75-D	86-E	97-F	107-G	118-H	128
8	59,550 (68.0)									
10	37,350 (64.0)	38,900 (71.3)								
12	26,050 (59.8)	27,450 (68.4)	28,300 (73.2)							
15	16,800 (53.1)	18,050 (63.9)	18,800 (69.7)	19,250 (73.2)						
20	8,950 (41.6)	10,200 (56.9)	10,850 (63.8)	11,250 (68.3)	11,550 (71.8)					
25	4,950 (24.2)	6,150 (48.3)	6,800 (58.2)	7,200 (63.8)	7,450 (68.1)	7,700 (71.2)				
30		3,550 (38.3)	4,200 (51.6)	4,550 (58.6)	4,800 (63.8)	5,000 (67.5)	5,200 (70.5)			
35		1,750 (25.2)	2,400 (44.3)	2,750 (53.1)	3,000 (59.3)	3,200 (63.8)	3,350 (67.2)	3,550 (69.7)	3,650 (72.0)	
40			1,100 (35.9)	1,450 (47.1)	1,700 (54.7)	1,850 (59.9)	2,050 (63.8)	2,200 (66.7)	2,300 (69.3)	2,400 (71.2)
45				450 (40.5)	700 (49.8)	900 (55.9)	1,050 (60.4)	1,150 (63.6)	1,250 (66.5)	1,400 (68.7)
50								400 (60.5)	450 (63.7)	550 (66.1)
Minimum boom angle (°) for indicated length (no load)		0	22	35	45	51	56	59	63	65
(ft.) at 0° b	ooom length ooom angle load)					43				

NOTE: () Boom angles are in degrees.

#LMI operating code. Refer to LMI manual for operating instructions.

	Lifting Capacities at Zero Degree Boom Angle											
Boom		Main Boom Length in Feet										
Angle	31.7	43-A										
0°	3,700 (27.5)	600 (38.8)										

NOTE: () Reference radii in feet.